

1. HOW TO SWITCH SCREEN



MODE	KEY	OPERATION	
DMB		CHANNEL UP (PRESS SHORT)	12 O'clock -> channel UP (*KOREAN GPS BOX)
		CHANNEL DOWN (PRESS SHORT)	6 O'clock -> channel DOWN (*KOREAN GPS BOX)
PIP (AV, REAR CAM)		PRESS FOR 3SEC	Switch the PIP mode on AV screen Switch the PIP mode on rear view ( FULL -> 2:1 -> 1:2 )
AV1~2		PRESS FOR 3SEC	Switch the AV screen (turn to connected device)

※PRESS "MENU" BUTTON TO SWITCH SCREEN※


2. MODE CHANGE FOR AV



ORIGINAL



AV



ORIGINAL

ORIGINAL FILL SCREEN



AV FULL SCREEN

3. HOW TO SWITCH THE REAR VIEW CAMERA




ORIGINAL

REAR VIEW CAMERA SCREEN (1:2)



REAR VIEW CAMERA SCREEN (1:2)

ORIGINAL




REAR VIEW CAMERA SCREEN(FULL)

4. HOW TO SET S/W MODE [ (ON) 0 : ↓ off on / (OFF) 1 : ↑ off on ]




DIP\_SW1 : Navigation On/Off




DIP\_SW2 : AV1 On/Off




DIP\_SW3 : AV2 On/Off



DIP\_SW4 : REAR CAMERA On/Off



DIP\_SW5 : AUTOMATIC ON / MANUAL OFF




DIP\_SW6,7,8 : VEHICLE SETTING

[ (ON) 0 : ↓ off on / (OFF) 1 : ↑ off on ]

Off On		1,1,1 : 8.8"	Off On		1,1,0 : 8.8"
					X6
Off On		1,0,1 : 8.8"	Off On		1,0,0 : 6.5"
Off On		0,1,1 : 8.8"	Off On		0,1,0 : 8.8"
Off On		0,0,1 : 8.8"	Off On		0,0,0 : 6.5"

6. COMPONENTS



5. HOW TO ENTER NAV SETTING MODE



PRESS **OK** BUTTON 4 TIMES THEN YOU WILL SEE THE NUMBER **1** ON THE LEFT TOP OF THE SCREEN FROM 1~4 WHEN IT'S NUMBER 4, PRESS THE **OK** BUTTON TO ENTER THE SETTING

\* RGB :

7P PIN

